

**BOXER** *X125*  
MADE STRONGER TO LAST LONGER

# User's Guide (Export)



## Foreword



Dear Customer,

Congratulations on choosing **“Boxer X125”** motorcycle, one of the finest motorcycles in the country brought to you by Bajaj Auto Limited.

Before you prepare for riding, please read this User's Guide carefully to familiarize yourself with the mechanism and the controls of the vehicle.

To maintain your bike in perfect running condition and to deliver consistent performance, we earnestly advise you to avail periodic services, at Bajaj Dealers.

You can entrust Bajaj Dealers, who are well equipped with all necessary facilities, skill sets and trained manpower for servicing and repairs of your **“Boxer X125”**. In the rare event of going to a local garage, always insist on Genuine Bajaj Spares to ensure safety, performance and longer life of your vehicle.

Should you require any additional information, please approach Bajaj Dealers. If necessary, you may also write to selling Dealer, with relevant details like Registration no. Chassis no., Engine no., Date of purchase, Kms. run and your contact numbers.

Finally, may we request you to give your motorcycle a proper care and regular maintenance, as described in this manual. We are sure this will offer you a long trouble-free ownership experience.

Wishing you unlimited miles of happiness!

**DOC. NO. 71120050**  
**REV. 02, OCT. 2018**

**International Marketing**  
**BAJAJ AUTO LIMITED**  
Akurdi Pune - 411 035 India  
CIN-L65993PN2007PLC130076

## Table of Contents

### Description

1. Technical Specifications	1
2. Location of Parts	3
3. How to Ride Bike	14
4. Safe Riding Tips	18
5. Periodic Maintenance Information	20
6. Periodic Maintenance & Lub. Chart	25

### 7. Non-use Maintenance

28

### Safety and Warning information :



**Warning :** This indicates that a potential hazard or injury to you or other persons & to the vehicle can happen if advice provided is not followed



**Caution :** This indicates that a potential hazard that could result in vehicle damage. Follow the Advice provided with the caution.

**Notice:** The description and illustration in this booklet are not to be taken as binding on the manufacturers. The essential features of the type described and illustrated herein remaining unaltered. Bajaj Auto Limited reserves the right to carry out modifications on the vehicle, parts or accessories as may be convenient and necessary at any moment without being obliged to bring this booklet upto-date.

## Technical Specifications



<b>Engine</b>	: 4 stroke, single cylinder Natural air cooled, Spark ignition	<b>Front Brake</b>	: Mech. expanding shoe 130 mm dia. Drum
<b>Bore x Stroke</b>	: 52.0 mm x 58.6 mm	<b>Rear Brake</b>	: Mech. expanding shoe 130 mm dia. Drum
<b>Eng. Displacement</b>	: 124.45 cc	<b>Fuel Tank Capacity</b>	:
<b>Compression Ratio</b>	: 9.8 : 1	Full	: 11 liters
<b>Idling Speed</b>	: 1400 rpm $\pm$ 100	Reserve	: 1.5 liters
<b>Max. Net Power</b>	: 10 PS @ 7500 rpm	Usable	: 1 liters
<b>Max. Net Torque</b>	: 10.5 Nm @ 5500 rpm	<b>Dimensions</b>	:
<b>Ignition System</b>	: AC, DC	Length	: 2016 mm
<b>Spark Plug (1 Nos)</b>	: CHAMPION PRZ9HC	Width	: 770 mm
<b>Spark Plug Gap</b>	: 0.7~0.8 mm	Height	: 1134 mm
<b>Lubrication</b>	: Wet sump, Forced.	Wheel base	: 1285 mm
<b>Transmission</b>	: 5 speed constant mesh. (All down)	Ground clearance	: 184 mm
		Turning circle radius	: 2050 mm
		Saddle height	: 808 mm

## Technical Specifications



### Tyre Size

Front	:	2.75 X 17", 41 P Semi Knobby Type
Rear	:	3.00 X 17", 50 P Semi Knobby Type

### Tyre Pressure

Front	:	1.75 kg/cm <sup>2</sup> (25 PSI)
Rear (Solo)	:	2.00 kg/cm <sup>2</sup> (28 PSI)
Rear (Pillion)	:	2.25 kg/cm <sup>2</sup> (32 PSI)

**Electrical System** : 12 Volts (AC/DC)

Head Lamp

(w/o Pilot lamp) : 35/35W HS1

Neutral : 12V, 2W

Tail / Stop Lamp : 12V, 5/21W

Turn Signal Indicator : 12, 2W

Side indicator Lamp : 12V, 10W (4nos.-  
clear bulb)

Hi Beam Indi. Lamp	:	12V, 2W
Speedometer Lamp	:	12V, 2W
Fuel Meter lamp	:	12V, 2W
Horn	:	12 V 2 A
Battery	:	12 V 5 Ah MF

**Vehicle Kerb Weight** : 120 kg.

**Gross Vehicle Weight** : 253 kg.

**Max. Speed** : 100 km/hr.


**Climbing Ability** : 25% max. (14<sup>o</sup>)

### Note :

- *All dimensions are in UNLADEN condition.*
- *Above information is subject to change without any notice.*
- *Values given above are nominal and for guidance only. 15% variation is allowed to cater for production and measurement variation.*


## Location of Parts

**BOXER** *X125*  
MADE STRONGER TO LAST LONGER




## Location of Parts

The Frame and Engine serial numbers are used to register the motorcycle. They are the unique alpha-numeric codes to identify your particular vehicle from others of the same model and type.



### **Frame Number Location**

On LH Side of Steering Tube  
(Alpha-Numeric - 17 Digits)





### **Engine Number Location**

On LH Side Crankcase Near Gear  
Change Lever (Alpha-Numeric - 11 Digits)



### Steering cum Ignition Lock :

It has three positions.

	<b>LOCK</b> : Steering locked. Ignition OFF.
	<b>OFF</b> : Steering unlock. Ignition OFF.
	<b>ON</b> : Steering unlock. Ignition ON.

**To Lock the Steering** : To lock the steering, turn the handle bar to the left or right. Push & release the key. Turn the key to “LOCK” position and remove the key.

**To Unlock the Steering** : To unlock steering, insert the key in steering cum ignition lock & turn it clockwise to “OFF” or “ON” position.

**Key** : A common key is used for ‘Steering cum Ignition lock’, ‘Fuel tank cap’ & ‘Side cover lock’.




**Fuel Tank Cap**



### Fuel Tank Cap

- To open the fuel tank cap, insert the key in the lock and turn it clockwise and lift fuel tank cap.
- 'Fuel Tank Cap' is locked when pushed / pressed back into the place.

**Fuel Tap**



### Fuel Tap


Fuel tap lever has following positions.

**ON** : When fuel level is above Reserve position.



**RES** : When fuel level is below Reserve position.

**OFF** : When fuel supply is to be cut off.

## Location of Parts



1. **Odometer** : It shows the total distance that the vehicle has been ridden.
2. **Speedometer** : The Speedometer pointer shows the speed of the vehicle.
3. **Turn Signal Indicator (LH & RH)** : When Turn signal switch is turned to Left or Right, Turn pilot indicator LH or RH will flash.
4. **Hi Beam Indicator** : When Headlight is 'ON' & Hi beam is selected with engine running, Hi beam indicator will be lit.
5. **Fuel Level Indicator** : It shows available fuel in fuel tank.
6. **Neutral Indicator** : It illuminates when transmission is in Neutral & Ignition switch is 'ON'.



### Left Handle Bar Switches

**A. Dipper Switch :** When headlight is ON, High or Low beam can be selected with the dipper switch. Hi beam indicator light located on Speedo console will light up when high beam is selected.

☰○ : High Beam      ☷○ : Low beam

**B. Turn Signal Switch :** When the turn signal switch is turned to Left (↵) or Right (↶), the corresponding turn signals flash on and off. To stop flashing, push the switch in and release.

**C. Horn Button :** (🔊) Press horn button for sounding horn.

**D. Pass Switch :** Press the switch to flash the head light. It is used to give signal to vehicles coming from opposite side while overtaking.





### Right Handle Bar Switches

**D. Head Light Switch :** It has 2 positions.

● : All lamps 'OFF'.

☀ : While engine running, Head lamp,  
Tail lamp & Meter lamps 'ON'.

**E. Starter Button :** Electric starter operates only when the vehicle is in neutral position. Self start is not possible in gear engaged mode.



### Removal of Side Cover LH

- Insert the key into the cover lock (A) and turn the key clockwise.
- Hold the cover with both hands and pull front side (B) first & slide rear side (C) toward front side. Take out 'Side cover LH'.



**CAUTION :** Remove cover as described above, otherwise cover lugs may break.

### Fitment of Side Cover LH

- Match & insert the Lug C (rear side) in bracket mounted on chassis & slide 'Side Cover' LH toward rear side.
- Match 'B' lug provided on front side of side cover with hole provided on fuel tank & press side cover inside.



**CAUTION :** Ensure tool kit is fully inserted in tool kit slot.



### Removal of Side Cover RH

- Remove the screw (A) given on 'Side Cover'.
- Hold the cover with both hands and pull front side (B) first & rear side (C) later. Take out 'Side cover'.



**CAUTION :** Remove cover as described above, otherwise the lugs may break.

### Fitment of Side Cover RH

- Match rear side (C) of 'Side Cover' lug with hole located on chassis & press the cover.
- Match the Lug provided on front side (B) of 'Side Cover' with hole provided on 'Fuel Tank' & press 'Side Cover' inside.
- Match 'Side Cover' properly with bracket provided on 'Chassis' & fix it with Screw (A).




**CAUTION :** Fit cover as described above to ensure proper fitment.



Make of Battery may differ from vehicle to vehicle

### Battery


- It is located inside the 'Side Cover' LH.
- Always maintain electrolyte level in each cell between Max. & Min. level marks.

 **CAUTION** : Do not drive/run vehicle in battery disconnected condition. It may lead to damage of electrical / electronic components.



### Tool Kit Location

- It is located below the battery box.
- If tool kit is not inserted properly, then it may obstructs LH cover fitment.


 **CAUTION** : Ensure tool kit is fully inserted in tool kit slot.



**Fig. A**

### Removal of Seat

- Remove 2 nos. M5 Allen bolts provided for fixing of seat on LH & RH sided with M5 allen key.
- Lift the seat from rear side & pull it toward rear side.



**Fig. B**

### Fitment of Seat


- Match & insert the seat bracket 1 of Fig. B with slot 2 of Fig. B provided below the fuel tank.
- Push seat towards fuel tank. Align bracket 3 & 4 of Fig. B with respective bracket on chassis. Tighten the 2 nos M5 Allen bolts on LH/RH side.



### Starting The Engine :

- Turn the fuel tap knob to 'ON' or 'RES' position.
- Turn ignition switch key to 'ON' position.
- Confirm that transmission is in neutral.
- If the engine is cold or when starting for first time, use manual choke for quick starting. Choke lever is located on RH side of Carburettor.


### Manual Choke



- Release starter button / kick lever as soon as engine starts.
- When the engine is warmed up enough to idle without using choke, return the manual choke lever to OFF position.

**Note :** *Do not let the engine idle longer than 3 minutes otherwise it will overheat.*

**Caution :** Do not operate the starter continuously for more than 5 seconds otherwise battery would get discharged. Wait 15 sec. after successive 3 cranks, which will facilitate battery to recover.


- Keep throttle completely closed, press starter button “” / apply kick to start the engine.

## Moving off :


- Start the bike.
- Check that Center/Side stand is retracted.
- Depress the clutch lever.
- Shift the gear pedal into 1<sup>st</sup> gear.
- Open the throttle gradually & simultaneously release the clutch lever slowly.
- As the clutch starts to engage, open the throttle a little more, giving the engine just enough rpm to keep it from stalling.

## Shifting gears :

- Close throttle & pull in the clutch lever.
- Shift into next higher or lower gear as desired.
- Open the throttle and release the clutch lever slowly and simultaneously.



**A : Gear Shifting Lever**

 **Warning :** When shifting down to lower gear, do not shift at such high speed that engine rpm jumps excessively. This may cause engine damage, and rear wheel may skid. Downshifting should be done at recommended speeds as shown in table.

## Braking :

- Close the throttle completely, leaving the clutch engaged (except where shifting gears) so that the engine braking will help slow down the motorcycle.
- Shift down one gear at a time so that you are in Neutral when you come to a complete stop.
- When stopping, always apply both brakes at the same time. De-clutch as necessary to avoid engine stalling.


- Never lock the brakes, or it will cause the tyres to skid. When cornering, use brakes judiciously and do not de-clutch. Reduce your speed before you get into the corner. For emergency braking, disregard downshifting, and concentrate on applying brakes as hard as possible without skidding.

### Stopping the Vehicle :

- Close the throttle completely.
- Shift the transmission into neutral.
- Bring the vehicle to complete stop.
- Turn the ignition switch off.

### Parking the Vehicle :

- Support the motorcycle on a firm level surface with the center or side stand.
- Lock the steering.

 **CAUTION** : Do not park on a soft or steeply inclined surface or the motorcycle may fall over.

### Running IN

Proper running-in is important for the better engine life and trouble free performance of the vehicle.

- During first 2000 kms running-in period do not exceed following speed limits.

Kms	1st	2nd	3rd	4th	5th
0 - 1000	15	30	45	55	44
1000 - 2000	18	28	38	46	55

- Always keep the speed below the limits mentioned in the table.
- Do not race the engine excessively.
- Do not raise the engine rpm immediately after starting. Run the engine for a minute in idle speed to allow engine oil to reach all moving components.

### Fuel Saving Tips :

A well maintained vehicle and good driving can contribute a lot to the saving of petrol. Following are a few simple fuel saving tips.

#### Good Riding Habits :

- Ride smoothly and steadily at an optimum driving speed of 40 to 50 Km/h
- Avoid harsh braking.
- Change the gear judiciously according to the speed and load requirement.
- Don't overload the vehicle above the specified payload.
- Use the accelerator judiciously.
- Cut off the engine if you want to stop for more than two minutes.
- Ensure choke lever is in 'OFF' condition after engine get warm.

#### How to check mileage (Fuel efficiency)

Best way to calculate mileage is by following the full tank to full tank method.

- Fill way tank full up to small mouth (brim).
- Run the bike for say 100 km.
- Fill the tank full again in same fuel filling station, probably with same fuel dispenser.
- Divide kilometer run / fuel quantity filled.

### Optimum Shifting Speeds for best mileage

- 1st gear : 0 km/h
- 2nd gear : 14 ~ 17 km/h
- 3rd gear : 22 ~ 25 km/h
- 4th gear : 31 ~ 34 km/h
- 5th gear : 38 ~ 42 km/h

### Ensure following maintenance points to get optimum fuel efficiency from your bike.

Fuel	Check fuel lines & connections for leakage.
Spark plug	Inspect and clean spark plug. Adjust electrode gap.
Air filter	Clean air filter element periodically.
Engine oil	Check level. Use recommended grade and quantity.
Brakes	Ensure that the brakes are not dragging / binding.
Clutch	Ensure correct clutch lever play.
Tyre Pressure.	Always maintain recommended tyre pressure.
Carburettor	Clean & adjust the carburettor. Adjust idling speed.

### Safe Riding Tips

- Always wear helmets while driving or riding. Your helmets should conform to appropriate International standards.
- Read thoroughly the instructions in this manual and follow them carefully.
- Avoid unnecessary accessories for the safety of both rider and other motorists.
- Get familiar and follow traffic rules & regulations in your States as well as general traffic signs.
- Familiarise yourself well with starting, acceleration and braking of the vehicle.
- When applying the brakes, use both front and rear brakes simultaneously. Applying only one brake may cause the vehicle to lose control.
- Riding at proper speed and avoiding unnecessary acceleration and



braking are important not only for safety and low fuel consumption, but also for longer life of the vehicle.

- During monsoon drive the vehicle more cautiously. Remember vehicles skid more easily during light showers..
- Drive cautiously. Start early & reach your destination safely.
- Always carry vehicle registration & insurance papers, and a valid driving licence with you.
- Avoid driving on loose sand or stones where vehicle is likely to skid.
- Properly wrap-up loose clothes while driving or riding to avoid entangling in wheel or other objects on road.
- Always concentrate on riding for safety.

### Daily Safety Checks :

Before riding motorcycle be sure to check following items. Please give proper importance to these checks and perform all of them before riding motorcycle.

## Safe Riding Tips

If any irregularities are found during these checks, refer to the Maintenance chapter & see your dealer for the action required to return the motorcycle to a safe operating condition.


**Warning :** Failure to perform these checks every day before you ride may result in serious damage or severe accident.

- Enough **fuel level** for planned distance of journey. No fuel leakage in fuel lines.
- **Engine oil** level (between upper - lower level mark)
- **Throttle cable** play of 3 - 4 mm. Smooth operation & positive return to closed position,
- **Steering Lock** lever not fouling.
- **Brake Pedal** Play 15 to 20.
- **Wear lining Indicator** within usable range. No brake dragging.
- **Drive Chain** slack of 25 to 30 mm adequately lubricated.
- Function of all **lights & horn**
- **Clutch lever** play - 2 to 3 mm

- Smooth **steering movement** without restriction
- **Both stands** return to their fully up position.
- Correct **inflation pressure** in both tyres  
Adequate tyre tread depth- no cracks / cuts.
- Correct **rear viewing** span adjustment of mirror.

### Monsoon Care :

- Take appropriate care in areas of heavy rainfall or high humidity. An appropriate surface protection of external part is recommended.
- Vehicle cleaning to be done with soft & clean wet cloth to avoid scratches on painted parts.
- Clean & lubricate all the important parts as detailed in the periodic maintenance chart.
- Do not apply direct water jet on painted, electrical / electronic parts.
- Do not obstruct engine cooling by adding mud protection sheet from front.



**A : Oil filler cap**  
**B : Oil level gauge**

**C : Upper level**  
**D : Lower level**

### Engine Oil : Check every week

- Always maintain engine oil level between the upper (C) and lower (D) mark provided on Clutch cover.
- Replace the oil in accordance with periodic maintenance chart.

### Engine Oil Level Checking :

- Park the vehicle on center stand, perpendicular to the ground on a firm, level surface.
- Check oil level through oil level inspection window 'B'.

Recommended	SAE 20W50 API 'SL' / JASO 'MA'
Oil Capacity	1.1 L Refill - 0.9 L

It is most vital to adhere to recommended frequency of oil change for the purpose of long life of critical engine components. For details refer periodic maintenance chart.

### Oil Strainer

- Oil strainer is situated inside Clutch cover.
  - Oil Strainer should be cleaned periodically at Vehicle Dealer / Authorised Service Center.
- **Engine oil Replacement Frequency : 1st service & then every 5,000 Kms.**

## Periodic Maintenance Information

### CAUTION :

- It is most important to adhere to recommended grade & frequency of oil change for the purpose of long life of critical engine components. For details refer periodic maintenance chart.
- Do not reuse drained oil.

### Wheel Puncture :



Use the recommended levers while removing the Tyre / Tube for puncture work. This will avoid any damages to the edges / scratches on paint of the wheel.

### Tyre Pressure :

Keep appropriate tyre pressure as mentioned below to increase life of the tyre & for better fuel consumption.

Front	1.75 Kg/Cm <sup>2</sup> (25.0 psi)
Rear (Solo)	2.00 Kg/Cm <sup>2</sup> (28.5 psi)
Rear (with Pillion)	2.25 Kg/Cm <sup>2</sup> (32.0 psi)

**Note :** In case the motorcycle is fitted with imported tyres, compliance to International standards.



### Battery Maintenance :



#### Battery type : 12V 5Ah

- Add only distilled water to the battery if battery electrolyte level is below min. level mark.

**⚠ CAUTION :** Tap water is not a substitute for distilled water and will shorten the life of the battery.

- When battery is found discharged, it is advised to get it charged immediately.
- Environment care must be taken to dispose off the used battery. It is always recommended to hand over the same to the Authorised battery dealer for proper disposal of the same.

#### How to keep battery healthy ?


- Switch 'Off' ignition when engine is not running.
- Get battery checked/ charged during periodic services.
- Do not press starter button for more than 5 sec. After 3 successive cranking, wait for 15-20 sec. for battery to recover.
- Disconnect battery +ve & -ve wires if vehicle is to be stored for more than 2 weeks. This avoids self discharge.

### Spark Plug

- Remove spark plug by using plug spanner.
- Clean the spark plug.
- Adjust the gap if incorrect by bending outer electrode carefully.

**Spark Plug Gap** : 0.7 to 0.8 mm.


**Spark Plug** : Champion PRZ9HC



### Drive Chain Slackness

- Chain top edge to be kept between the two marks during chain slackness adjustment.
- Care should be taken, that the chain should never run dry. Lubricate chain from outside with SAE 90 oil at every 500 kms.
- Chain slackness will have to be adjusted whenever required.





**Cleaning**

### **Drive Chain**

- Lubricate chain every 500 kilometers with SAE 90 oil.
- Check & if required adjust chain slackness (whenever required).
- Remove, clean, inspect and lubricate (overhaul) drive chain at every 5,000 kilometers.

### **Method of chain lubrication :**

- Remove chain covers & drive chain link lock
- Take out drive chain.



**Chain Lubrication**

- Clean the chain with nylon brush by using kerosene/ with the help of chain cleaning machine.
- After cleaning, dip chain in SAE 90 oil.
- For effective lubrication recommended chain spray can be used. Spray the lubricant into clearance between drive chain roller & bush. Wipe out excess lubricant by using lint free cloth.

## Periodic Maintenance & Lubrication Chart

Sr. No.	Operation	RECOMMENDED FREQUENCY								
		Servicing	1st	2nd	3rd	4th	5th	6th	7th	
		Kms	750	5000	10000	15000	20000	25000	30000	
1.	Servicing		✓	✓	✓	✓	✓	✓	✓	1st - 750 Kms / 30 Days 2nd onward @5000 Kms
2.	Engine idling speed / CO%	A	A	A	A	A	A	A	A	
3.	Valve tappet clearance	A	A	A	A	A	A	A	A	
4.	Engine oil	R	R	R	R	R	R	R	R	20W50API SL JASO MA Grade
5.	Oil strainer	CL	CL	CL	CL	CL	CL	CL	CL	Clean at 5000 Kms
6.	Paper oil filter	R	R	R	R	R	R	R	R	Replace at every oil change
7.	Spark plug functioning / Gap	C,A,R	C,A	C,A	C,A	R	C,A	C,A	R	Replace at every 15000Kms
8.	Air cleaner element Clean* / Replace	CL,R	CL	CL	CL	R	CL	CL	R	Clean at every 5000Kms Replace at every 15000Kms
9.	Air filter cover 'O' Ring	R					R			Replace at every 20000Kms
10.	Fuel cock sediment bowl cleaning	CL		CL	CL	CL	CL	CL	CL	Clean at every 5000 kms
11.	Carburettor float bowl cleaning	CL			CL		CL		CL	Clean at every 10000Kms
12.	Carburettor rubber duct	C,R	C	C	C	C	R	C	C	Replace at every 20000kms
13.	Fuel pipes	C,R	C	C	C	C	R	C	C	Replace at every 20000kms
14.	Battery electrolyte level	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
15.	Clutch lever free play	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	

\* More frequent cleaning may be required when driving in dusty condition.

## Periodic Maintenance & Lubrication Chart



Sr. No.	Operation	RECOMMENDED FREQUENCY								
		Servicing	1st	2nd	3rd	4th	5th	6th	7th	
		Kms	750	5000	10000	15000	20000	25000	30000	
16.	Throttle grip play	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
17.	Rear brake pedal free play	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
18.	Brake lining or pad wear	CL,R		CL	CL	CL,R	CL	CL	CL,R	Replace at every 15000kms
19.	Brake cam & pedal pivot pin	L				L			L	
20.	Steering play	C,A	C,A	C,A	C,A	C,A	C,A	C,A	C,A	
21.	Steering stem bearing	C,L,R			C,L,R		C,L,R		C,L,R	
22.	All fasteners tightness	C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	
23.	Rear sprocket fasteners	C,T	C,T	C,T	C,T	C,T	C,T	C,T	C,T	
24.	Rear wheel rubber shock damper	C,R			C,R		C,R		C,R	Replace at every 10000kms
25.	Silencer drain hole cleaning	CL	CL	CL	CL	CL	CL	CL	CL	Clean at every 5000Kms
26.	Cylinder head de-carbonising, valve lapping & Replace valve oil seals	CL				CL			CL	Clean at every 15000Kms
27.	Engine air breather tube	R					R			Replace at every 20000Kms
28.	Drive chain slackness adjustment & lubrication	C,A,L	C,A,L	C,A,L	C,A,L	C,A,L	C,A,L	C,A,L	C,A,L	Lubricate at every 500kms. A- slackness whenever reqd.
29.	Drive chain remove, clean, insp. & lub. (O/H)	CL,L		CL,L	CL,L	CL,L	CL,L	CL,L	CL,L	At every 5000Kms
30.	Drive chain link lock	R		R	R	R	R	R	R	Replace at every 5000Kms

## Periodic Maintenance & Lubrication Chart



Sr. No.	Operation	RECOMMENDED FREQUENCY								
		Servicing	1st	2nd	3rd	4th	5th	6th	7th	
		Kms	750	5000	10000	15000	20000	25000	30000	
31.	Tyre tread wear	C,R			C,R	C,R	C,R	C,R	C,R	At every ser. after 2nd ser.
32.	General lubrication	L	L	L	L	L	L	L	L	

**C : Check, A : Adjust, CL : Clean, R : Replace, T : Tighten, L : Lubricate**

**Note :** Periodic parts / lubricants to be replaced as per Periodic Maintenance and Lubrication Chart are mandatory and the same are chargeable to customer.

Non-use maintenance is necessary if a vehicle remains off road for a longer duration (more than 15 days\*\*). The correct and careful non-use maintenance carried out before storing the vehicle will prevent the vehicle from rusting and from such other non-operational damages like fire hazards.

- Clean the entire vehicle thoroughly.
- Empty the fuel from the fuel tank and carburettor float bowl (if fuel is left in for a longer time, the fuel will break and gummy substance could clog the carburettor).
- Remove spark plug & put several drops of 2T oil into the cylinder. Kick engine over slowly a few times to coat cylinder wall with oil & install back spark plug.
- Set the vehicle on a box or a stand so that both wheels are raised off the ground.
- Spray oil on all unpainted metal surfaces to prevent rusting. Avoid getting oil on rubber parts or brake liners.
- Lubricate the control cables.
- Cover entire vehicle neatly. Make sure that storage area is well ventilated & free from any source of flames or spark.
- Fill 10% excess air pressure in both wheels.

### **\*\* For Battery :**

- a. Remove battery and keep it on wooden plank, in properly ventilated area.
- b. Before taking the vehicle for use.
  - Get the battery recharged from an Authorised Service Center.
  - Check and correct the electrolyte level and apply petroleum jelly on terminals (applicable to certain models).

### **Preparation for regular use after storage :**

- Clean the vehicle
- Make sure the spark plug is tight.
- Fill the fuel tank with fuel.
- Change the engine oil.
- Check all the points listed in the Daily Safety Checks section.
- Check and inflate tyres to proper tyre pressure.

# Use only Bajaj Genuine Parts

**BOXER** X125  
MADE STRONGER TO LAST LONGER



**BAJAJ**  
**GENUINE**  
**parts**

Use only Bajaj Genuine Parts

- For optimum performance of vehicle
- For prolonged life of components & vehicle
- For economical maintenance cost
- For rider's safety

## Genuinity Test



Scratch Hologram to find 'Genuine'  
Partial transparent Hologram



Golden Hologram

**BAJAJ**

**DTS-i OIL**

**BEING THE DESIGNER OF THE ENGINE WE  
KNOW BEST ABOUT ITS LUBRICATION NEEDS**



*Longer Oil Replacement*



*Cleaner Engine Parts*



*Reduced Friction*



*Smooth Clutch Control*

**Contact your Authorized Workshop**

**PERFORMANCE  
MULTIPLIED**



**Conform to International Specifications  
of API SL and JASO 'MA2'.**



**GRADE**

**RETAIL PACKS**

20W50

1 LITRE & 1.2 LITRE & 100 ML

10W30

1 LITRE & 100 ML



**BOXER** *X125*  
MADE STRONGER TO LAST LONGER



**Bajaj Auto Limited**  
Akurdi Pune 411 035 India

Tel +91 20 27472851  
Fax +91 20 27407385  
[www.globalbajaj.com](http://www.globalbajaj.com)

CIN-L65993PN2007PLC130076